

Universal Flat Post Driver

Fact Sheet

Part# RHD-44-A



Opening Dimensions

1 1/4



4 3/4

The Universal Flat Post Driver comes custom fabricated to accommodate all of our flat posts, from our Rhino Hybrids to standard fiberglass posts and can be quickly and easily installed in three easy steps. A burial depth of 18" to 24" is recommended. In difficult soil conditions and rough terrain, the Universal Flat Post Driver can be used in combination with the Pilot Hole Driver (PHD-100-A) to quickly prepare the ground with a starter hole.

Description:

- The Universal Flat Post Driver is composed of heavy-duty steel and is designed for easy installation of flats posts and markers.

Installation:

1. Remove marker from carton. Insert into the Universal Flat Post Driver with the pointed end out.
2. Rotate driver and marker into the correct position to install.
3. Drive marker with light taps into the ground with your foot braced against it to control buckling. Repeat until you reach burial depth of black line on post, while maintaining correct alignment of marker.

Options & Add-Ons



Pilot Hole Driver for
hard/rocky soil conditions
Part# PHD-100-A